

gb – Instruction for use

# AutoAssistent



---

## Table of contents

About this document .....	3
Contact.....	3
Intended use .....	3
Maintenance and care .....	4
Replacement of the paper clip .....	4
Assembly and adjustment.....	5
Usage.....	6
Closed storage space .....	6
Clipboard.....	6
Open storage space.....	6
Accessories.....	7

## About this document

Comply with the following aspects for save use of the product.

- ▶ Read this document carefully before use.
- ▶ Keep this document for subsequent reference
- ▶ Pass this document onto the end user and the vehicle user.


This document forms an integral part of the product and is an important component of the safety concept. Failure to comply can lead to serious injury death.


## Contact

Do you have any questions about your product? You can find your personal contact on our website.



## Intended use

	<b>Important!</b>
<p>The Auto-Assistant is only intended for use as a means of transport and equipment for office documents. It is primarily designed for use on the passenger seat of a vehicle. When used in the vehicle it is imperative, that the safety belt is securely fastened before setting off.</p>	

	<b>Danger!</b>
<p><b>Danger from an unsecured Auto-Assistant</b> Severe or fatal injuries can result from the Auto-Assistant being incorrectly secured.</p> <ul style="list-style-type: none"><li>▶ Check the safety belt for damage defects.</li><li>▶ Make sure that the belt lock is properly engaged.</li></ul> <p><b>Personal injury and material damage from unsecured load</b> Braking, acceleration, taking bends or swerving causes forces on the cargo. The load can slide and fly around. This can result in personal injury and material damage.</p> <ul style="list-style-type: none"><li>▶ Note the maximum load-bearing capacity of <b>12 kg</b>.</li><li>▶ Lock the Auto-Assistant before setting off.</li><li>▶ Make sure that the load is evenly distributed.</li></ul>	

## Maintenance and care


Check the following elements regularly for wear or damage.

- Safety belt,
- Auto-Assistant restraint system,
- Cover lock

**Interval:** At least every 5000 km.  
e.g. emergency braking.

**Care:** Clean the Auto-Assistant with a wet cloth if dirty. Avoid harsh cleaning agents, as they could damage the Auto-Assistant.

## Replacement of the paper clip

<p><b>Insert spring</b></p> <p>Spring must snap correctly on both sides.</p>	
<p><b>Position paper clip</b></p> <p>Position the paper clip so that the stop is on the left.</p>	
<p><b>Insert paper clip</b></p> <p>Insert the pin of the clamp into the left receptacle (1) and then press right down (2) until the pin audibly snaps into place.</p>	

## Assembly and adjustment



### Danger!

#### Risk of injury due to incorrect installation

Severe or fatal injuries can result from the Auto-Assistant being improperly or incorrectly installed.

- ▶ Refer to the instructions in this manual for installation.
- ▶ Make sure that the safety belt is undamaged.
- ▶ Do not fit an Auto-Assistant with a damaged restraint system.



### Information!

Move the seat into its rearmost engagement position for ease of installation. The use of a seat protector is recommended to protect the seat cover and prevent possible wear and abrasion.


#### Step 1

Position the Auto-Assistant centrally on the seat.



#### Step 2

Pass the lap belt through the front restraint system.



#### Step 3

Now pass the shoulder strap into the rear restraint system.






#### Step 4

Close the belt lock and tighten the safety belt.

## Usage

The Auto-Assistant offers various potential uses and functions.

<p><b>Closed storage space</b></p> <p>Inside the Auto-Assistant there is a large storage space, which can be divided up with the enclosed dividers.</p>	
<p><b>Clipboard</b></p> <p>A paper clip is located on the top of the Auto-Assistant, which is used to hold sheets of paper in place on the work surface.</p> <p><b>Hint:</b> The paper clip is only intended for clamping documents. Replacement of the paper clip, see „Maintenance and care“.</p>	
<p><b>Open storage space</b></p> <p>An open storage space is located at the rear, which can be used as storage for documents and bottles.</p>	

## Accessories

An office organizer for the backrest of the seat can be ordered to increase the storage space.

(Art. no.: 6000013636)



